

**CONTENTS**

- Truck Camper Cover
- Storage Bag
- Ladder Cap Reinforcement Cover
- Rain Gutter Reinforcement Covers
- Adhesive Reinforcement Material
- Weighted Tie Down buckles

1. Ensure that you have purchased the correct size cover for your truck camper. Visit [ADCOprod.com](http://ADCOprod.com) to review sizing. Measure your truck camper from end to end including bumpers spare tire and ladder, excluding hitch (where applicable) and mirrors that extend beyond the front of the coach. If you have any doubts, call ADCO at (800)541-2326 to speak with customer service.
2. Clean your truck camper thoroughly. Otherwise, you run the risk of black streaks.
3. Pad all sharp edges on the truck camper, to include rain gutters (use the included rain gutter covers), steps, ladders (use the included ladder cap), and abrasive corners. The cover may shift in the wind and could tear if sharp edges are not properly padded. ADCO does not warrant this product against wind damage. (You will want to cover the ladder cap last so that it's usable during installation)

**NOTE: Installation does not require you to climb on the roof. A step ladder may be used. It is however much faster to install if you are able to safely walk on your truck camper's roof.**

4. Unroll the Truck Camper Cover adjacent to your trailer. Unwind the straps and buckles.
5. Turn the cover inside out while it's on the ground.
6. Roll it back up loosely so that the FRONT tag is the last part that's not rolled up.
7. Grab the front tag in your hand, and climb the ladder.
8. Turn around from the roof and pull the cover up onto the roof (like you are pulling up a fire hose).
9. Walk the cover to the front of the truck camper, Front tag still in hand. Toss the front of the cover towards the ground.
10. Begin spreading out the cover. If it was properly turned inside out, the sides should almost fall into place.

[www.ADCOprod.com](http://www.ADCOprod.com)

11. Ensure that the sides fall most of the way to the ground – far enough to where you can grab them once standing on the ground.
12. Begin your decent down the ladder, installing the ladder cap on your way – then pull down the cover over the back of the coach.
13. Before any bottom corners are secured, straighten out the cover on the coach so that it's centered properly. Only then should you secure the bottom corners. Once they are in place, do not make further adjustments or pull the fabric – or you risk tearing the cover.
14. Adjust the straps and buckles located at each end of the truck camper Cover. Doing so will secure any excess fabric and prevent shifting in light wind.
15. Finally, secure the bottom straps and buckles. Use the weighted tie down buckles to help toss the straps beneath the coach. Cover traps should be moderately tight. Do not over tighten No additional straps, buckles, or rope should be used or you risk damaging your rubber roof or causing abrasion to the trailer's finish.
16. When you become a pro at covering your truck camper, it should take no more than 15 minutes.

**Taking the Cover Off Your Truck Camper...**

17. Disconnect the straps and buckles from the bottom, front and back of the truck camper.
18. Pull the cover off the front and rear corners.
19. Climb up the ladder while pulling the cover as you go.
20. Carefully walk to the front of the truck camper, avoiding A/C units and any portion of the cover that's not flat on the roof. Pull the front of the cover up onto the roof.
21. Now pull the sides up onto the roof, turning inside out and forming a strip of cover that spans the length of the roof.
22. Starting from the rear of the truck camper, roll the cover up so that the FRONT tag is left exposed at the end of the roll. Toss the rolled cover to the ground. The next time you use it, it should be ready to repeat the process.